



Funded by  
the European Union

# SQANTI-reads

Quality assessment of long-read data in multi-sample lrrNA-seq experiments

*Tianyuan Liu*

LongTREC Summer School 2025

LongTREC - The Long-reads TRanscriptome European Consortium  
Marie Skłodowska-Curie grant agreement No 101072892


- ① Background
- ② Introducing SQANTI-reads
- ③ Case Studies
- ④ Summary

# Section 1




Background


- Long-read RNA sequencing directly sequences **full-length cDNA molecules**, preserving isoform structure <sup>[1]</sup>.



Source: Monzó et al., 2025




Source: GENCODE (Frankish *et al.*, 2025)




*Errors: library preparation (RT switching, degradation), sequencing chemistry, or genome alignment.*

# Reverse Transcriptase Template Switching (RT-switching)



RT enzyme can "jump" between templates at repeated regions, creating chimeric cDNA products that confound transcript analysis.



Oligo-dT primers can bind to internal A-rich regions, causing truncated cDNA synthesis.



## Why rigorous QC is essential

- QC filters problematic reads, ensuring reliable downstream **quantification** and **novel isoform discovery** [3].
- Facilitates cross-sample comparison and prevents confounding technical artefacts.

## Limitations of traditional QC tools

- Most QC tools evaluate **read-level metrics** (length, Phred quality) but overlook **transcript structure**.
- Structural context is key for identifying mis-spliced or truncated reads [4].

1. What are the main advantages of long-read RNA sequencing over short-read sequencing for transcript analysis?
2. Can you name two major sources of error that can occur during lrrNA-seq library preparation?


# Section 2



Introducing SQANTI-reads

## A read-centric extension of SQANTI3

- Ports **SQANTI3** structural classification to the **single-read** level.
- Jointly evaluates *raw reads* from **multiple samples** in one run.
- Summarises structural categories, splicing patterns, and junction usage.
- Produces *interactive* visualisations to spot outliers and under-annotated genes.



## Core Inputs


- **Design file (CSV)** – columns sampleID, file\_acc.
- **Reference annotation** (GTF/GFF3).

## Mode – dependent

- *Fast mode*: pre-computed SQANTI3-QC output directories (given via `--input_dir`).
- *Simple mode*: raw reads (\*.fastq) or sample GTF/GFF  
+ reference genome FASTA.

## Key Outputs

- Modified reads\_classification.txt (adds jxn\_string, jxnHash).
- Updated design.csv (adds classification\_file, junction\_file).
- Summary CSV tables: gene\_counts, ujc\_counts, length\_summary, cv, etc.
- QC plots PDF (default) & optional HTML report.
- Annotation plots PDF.



*Schematic of a canonical eukaryotic gene: promoter (blue), untranslated regions, coding exons (orange), introns (grey), and transcriptional orientation from 5' to 3'.*

- Both share the first eight columns: seqid, source, type, start, end, score, strand, phase.
- **Attribute syntax**
  - **GTF**: <key> "value"; (semicolon-terminated key–value pairs).
  - **GFF3**: key=value (comma-separated if multiple) with ID / Parent tags enabling feature hierarchies.
- **Specification status**: GTF is legacy (GFF2-derived); GFF3 is the current, more flexible standard.

## GTF


```
chr1 HAVANA gene      11869 14409 . + . gene_id "ENSG00000223972";
chr1 HAVANA transcript 11869 14409 . + . gene_id "ENSG00000223972"; transcript_id "ENST00000456328";
chr1 HAVANA exon       11869 12227 . + . gene_id "ENSG00000223972"; transcript_id "ENST00000456328"; exon_number "1";
chr1 HAVANA five_prime_UTR 11869 12009 . + . gene_id "ENSG00000223972"; transcript_id "ENST00000456328";
chr1 HAVANA CDS         12010 12057 . + 0 gene_id "ENSG00000223972"; transcript_id "ENST00000456328";
chr1 HAVANA three_prime_UTR 12058 14409 . + . gene_id "ENSG00000223972"; transcript_id "ENST00000456328";
```

## GFF3

```
chr1 HAVANA gene      11869 14409 . + . ID=gene0;Name=DDX11L1;
chr1 HAVANA transcript 11869 14409 . + . ID=transcript0;Parent=gene0;
chr1 HAVANA exon       11869 12227 . + . ID=exon0;Parent=transcript0;
chr1 HAVANA five_prime_UTR 11869 12009 . + . ID=futr0;Parent=transcript0;
chr1 HAVANA CDS         12010 12057 . + 0 ID=cds0;Parent=transcript0;
chr1 HAVANA three_prime_UTR 12058 14409 . + . ID=tutr0;Parent=transcript0;
```




# Key Features: Unique Junction Chain



Reads have variable TSS/TTS but share the same ordered splice junctions.  
Such reads collapse into **one** Unique Junction Chain

# Key Features: SQANTI3 Structural Category



Source: Pardo-Palacios *et al.*, 2024

No.	Metric
1	Mean read length
2	Median read length
3	Upper-quartile read length
4	Lower-quartile read length
5	% reads <1 kb
6	% reads 1–2 kb
7	% reads 2–3 kb
8	% reads >3 kb

- Captures depth and size bias to reveal degradation or protocol differences.

No.	Metric
9	% Full-Splice-Match (FSM) reads
10	% Incomplete-Splice-Match (ISM) reads
11	% Novel-In-Catalog (NIC) reads
12	% Novel-Not-in-Catalog (NNC) reads
13	% Antisense reads
14	% Fusion reads
15	% Genic-genomic reads
16	% Intergenic reads

- Describes transcript integrity and novelty at the single-read level.

No.	Metric
17	% FSM UJCs
18	% ISM UJCs
19	% NIC UJCs
20	% NNC UJCs
21	% Antisense UJCs
22	% Fusion UJCs
23	% Genic-genomic UJCs
24	% Intergenic UJCs

- Collapses reads with identical junction chains, highlighting transcript-level novelty.

No.	Metric
25	% Known–canonical junctions
26	% Known–non-canonical junctions
27	% Novel–canonical junctions
28	% Novel–non-canonical junctions

- Assesses splice-site accuracy—critical for long-read platforms.


No.	Metric
29	% Reads with RT-switching repeat
30	% Reads with intrapriming signature
31	% Reads containing $\geq 1$ non-canonical junction

- Flag well-known long-read artefacts to aid filtering.

No.	Metric
32	Total mapped read count
33	Mean reads per gene
34	Mean reads per UJC
35	Genes with $\geq 1$ FSM read

- Summarises usable expression breadth and sequencing efficiency.





## Key insights from PCA:


- Samples cluster by **sequencing technology**
- PC1 (56%) separates **cDNA ONT** from **dRNA ONT** and **cDNA PacBio**
- PC2 (35%) separates **dRNA ONT** from **cDNA PacBio**
- Clear technology-specific biases
- Enables outlier detection within technology groups

1. What is the difference between analyzing reads versus UJCs (Unique Junction Chains)?
2. Which SQANTI3 structural categories would you expect to see more of in high-quality vs. low-quality samples? Why might the percentage of FSM (Full-Splice-Match) reads be an important QC metric?

# Section 3




Case Studies




Triplicate transcriptome measurements of the WTC11 human cell line. Three long-read sequencing (LRS) library types were compared: cDNA PacBio Sequel II (cDNA PacBio), cDNA Oxford Nanopore MinION (cDNA ONT), Direct-RNA Oxford Nanopore MinION (dRNA ONT).


- PC1 (56% variance) separates **cDNA ONT** from PacBio and dRNA ONT.
- PC2 (35%) further discriminates **dRNA ONT** from **cDNA PacBio** libraries.
- Clear clustering indicates technology-specific QC signatures.




- High **positive** PC1 loadings: total number of reads, % NNC reads, and % UJCs in the NNC category.
- High **negative** PC1 loadings: Intergenic and Genic–Genomic reads.
- PC2 is dominated by read-length metrics (1–2 kb, 2–3 kb, > 3 kb).



- **cDNA ONT** libraries show the highest proportion of **NNC UJCs**.
- **dRNA ONT** and **cDNA PacBio** display lower UJC novelty, mirroring their lower NNC read fractions.
- Reinforces PCA PC1 loadings that highlight splice-junction novelty as a driver of variance.




- **cDNA ONT** exhibits the highest proportion of NNC reads and UJCs.
- **cDNA ONT** also shows the lowest fraction of intergenic reads.
- Confirms PC1 loadings and underscores library-prep biases.





- **cDNA PacBio** enriched for longer reads (1–2 kb, 2–3 kb, higher than 3 kb).
- **dRNA ONT** dominated by reads < 1 kb.
- Aligns with strong read-length contributions to PC2.








1. What would you conclude if you saw a sample that clustered away from its expected technology group in PCA?

# Section 4



Summary

- **Multi-sample dashboards:** stacked bars and heatmaps instantly reveal QC metric trends across libraries.
- **PCA explorer:** Scores & loadings plots pinpoint outliers, batch effects and technology biases.
- **Structural maps:** side-by-side visualisation of Unique Junction Chains and SQANTI3 categories clarifies read novelty.
- One-click toggle between *reads*, *UJCs* and *gene*-level views—all colour-coded with the SQANTI3 palette.

-  Frankish, Adam et al. (2023). “GENCODE reference annotation for human and mouse genomes”. In: *Nucleic Acids Research* 51.D1, pp. D100–D110. DOI: [10.1093/nar/gkac836](https://doi.org/10.1093/nar/gkac836).
-  Galalde, Daniel R. et al. (2018). “Highly parallel direct RNA sequencing on an array of nanopores”. In: *Nature Methods* 15.3, pp. 201–206. DOI: [10.1038/nmeth.4577](https://doi.org/10.1038/nmeth.4577).
-  Monzó, Cristina, Tianyuan Liu, and Ana Conesa (2025). “Transcriptomics in the era of long-read sequencing”. In: *Nature Reviews Genetics* 26.5, ??? DOI: [10.1038/s41576-025-00828-z](https://doi.org/10.1038/s41576-025-00828-z).
-  Soneson, Charlotte et al. (2019). “A comprehensive examination of Nanopore native RNA sequencing for characterization of complex transcriptomes”. In: *Nature Communications* 10.1, p. 3359. DOI: [10.1038/s41467-019-11272-z](https://doi.org/10.1038/s41467-019-11272-z).
-  Tardaguila, Manuel et al. (2018). “SQANTI: extensive characterization of long-read transcript sequences for quality control in full-length transcriptome identification and quantification”. In: *Genome Research* 28.3, pp. 396–411. DOI: [10.1101/gr.222976.117](https://doi.org/10.1101/gr.222976.117).

# Thank You!

---



**Questions? Reach out at:**

<https://longtrec.eu>

